

Installation Instructions for Signage, such as
CC-ALU 'Man Running' + 'Directional Arrow'
CC-RIGID Stair Identification Signs, Floor ID Signs

1. Make sure the installation surface has no paint coming loose. Remove any flaky paint with a scraper and any surface unevenness with sandpaper. Brush off the surface area where the product will be installed. Afterwards wet-clean the surface with a moist microfiber cloth (better than paper towel) to remove any dirt or grime thoroughly. Prior to sign installation, the surface must be dry, dust-free and clean.



2. Hold sign in place, measure proper height, level and apply fine pencil marks for proper position. Double-check that sign carries the correct message for THIS floor/ this location. Remove adhesive-protecting liner. Do not touch adhesive. Hold sign along its edges.



3. Firmly press-apply sign by hand, then use a Pressure Roller to apply firm and even pressure onto the sign to ensure its adhesive backing comes in full contact with the installation surface. Make sure roller head carries no adhesive remnants from other projects.



Item-No.: 86-7006



4. Some signs have a clear (bluish) thin surface-protecting film applied. Once such a sign is properly installed and pressure-rolled on, remove that film and discard it.