

**Installation Instructions
for PERMALIGHT[®] Colored Aluminum Sign with
Photoluminescent Lettering: EXIT**

Letter Height: 7 inches **unframed Aluminum Plate**

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

Activation: minimum 5 foot candles (54 lux) of unfiltered fluorescent lighting for 60 minutes
CAUTION : EXTERNAL ILLUMINATION SOURCE REQUIRED

- Install PERMALIGHT[®] photoluminescent EXIT signs only in locations, where an external illumination source is present, is deemed reliable and is supplied by a circuit not controlled by automatic timers or sensors, and whose controls are accessible only to authorized personnel. This reliable external illumination source is to be energized at all times during building occupancy!
- Should any changes in your external lighting types or lighting levels occur, make sure that the PERMALIGHT[®] photoluminescent EXIT sign is still being illuminated with minimum 5 foot candles (54 lux) of unfiltered fluorescent lighting.
- Periodically clean the PERMALIGHT[®] photoluminescent EXIT sign face with non-abrasive cloth dampened with water. Do not use any thinners or chemical solvents on the sign face.
- Check with your applicable installation codes (such as NFPA 101 – Life Safety Code) to perform periodic visibility tests.
- PERMALIGHT[®] photoluminescent EXIT signs are intended for INDOOR use only. Do not expose to direct sunlight, liquid spray, or temperatures outside the range 10° C – 40° C (50° – 104° F).

Viewing Distance: 50 foot viewing distance

SAVE THESE INSTRUCTIONS

Installation: 4 screw holes provided for flat wall mount.
Hold sign flat against the wall and adjust height using a level. Mark the location of the four holes. Drill holes. Insert anchors, if needed. Then screw-attach sign in place.

Item-No.:	Description
600001	Red panel, 7" EXIT
600002	Red panel, 7" < EXIT
600003	Red panel, 7" EXIT >
600004	Red panel, 7" < EXIT >
600005	Green panel, 7" EXIT
600006	Green panel, 7" < EXIT
600007	Green panel, 7" EXIT >
600008	Green panel, 7" < EXIT >

Mounting Clips for unframed EXIT signs

If you want to hang an unframed sign from the Ceiling or Flag/ Side Wall Mount, use this Set of Two Mounting Clips:



Two L-shaped Mounting Clips for one unframed sign
Dimensions: 1 in x 1 in
Item No.: 600123